		on																										
Mode	Startup	Duration (min)	0	15 3	30 45	60	75	90	105	120	135 1	150 1	165 1	30 1	.95 2:	10 22	24	0 25	5 27	0 2	85 3	00 3	15 33	30 34	5 36	50 375	390	405 300
Step	Procedure	m Da																										
Prelim	nary Preparations																											
1	Preliminary inspection of plant sub-section	60																										
2	Remove shutdown blinds and install running blinds	30																										
Auxilia	ry Equipment and Utilities Start-up																											
3	Testing of electrical appliances and controls	15																										
4	Preparation of cooling water system	10																										
5	Preparation of steam system	10																										
	Start-up fan F201 and electric heaters H201 and H203	5																										
Elimina	ition of Air and leak prevention																											
7	Purge of units with nitrogen	60																										
8	Pressurisation of units	15																										
9	Tightness testing and bolt tightening	45																										
Initiati	on of onstream units																											
10	Opening hydrogen feed line	5																										
11	Pressurisation and heating of R201 to 5 atm, 60°C	10																										
	Open hydrogen recycle purge	5																										
13	Introduce set amount of methanol into column S201	5																										
14	Allow level in the reboiler and condenser to build-up	15																									\perp	
	Turn on pump P201	5																									<u> </u>	
	Gradually open liquid feed line to reactor and distillation column	60																										
	Open valves on distillation products take-off lines	5																										
Downs	tream Preparations																											
18	Start-up of downstream units	210																·			·							